






CAUTION:

Do not look directly into the light source. Doing so can cause serious and irreparable eve damage.

BATTERY INSTALLATION

Tool required - Small Phillips head screwdriver

- 1. Using a Phillips head screwdriver, remove the battery cover as shown.
- 2. Insert 4 "AA" batteries as indicated in the battery compartment and replace cover.



BATTERY SAFETY INFORMATION

- Non-chargeable batteries are not to be recharged
- Rechargeable batteries are only to be charged under adult supervision
- Rechargeable batteries are to be removed from the toy before being charged
- Different types of batteries or new and used batteries are not to be mixed - Batteries are to be inserted with the correct polarity
- Exhausted batteries are to be removed from the toy
- The supply terminals are not to be short-circuited


AA/LR6 X4 Batteries not included Requires 4 x 1.5V AA/LR6 batteries

IMPORTANT: For best 3D image projection, use in a completely darkened room.

3D glasses are only for viewing 3D images. Do not wear for long periods of time or while performing physical activities. Not to be used as sunglasses.

SET UP AND OPERATION

- 1. Use the product in a room with a smooth white wall or ceiling.
- 2. Place the projector unit in the base, aligning it with the base guide as shown. You can now position the projector unit at the desired angle.
- 3. The projector should be about three to five feet from the projection surface.
- 4. Focus as needed turning by the Focus Adjustment.
- Rotate Image Selection Dial to select image.



KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD

Questions? Visit unclemilton.com